

MONT BLANC COMMERCIAL ROOF BAR GUIDE - 18/03/2016

VEHICLE DETAILS								MB ProRack					MB ProRack				
MANUFACTURER	MODEL	TYPE	BODY STYLE	BODY STYLE CODE	YEAR START	YEAR END	MODEL REFERENCE	PRORACK FOOT PACKS (Sold In Pairs, 2 Feet)	PRORACK ROOF BARS (Single Bar)	PRORACK LOCKS	MIN NO. BARS	MAX NO. OF BARS	Rack Large 3 Bars	Rack Medium 2 Bars	Rack Medium 3 Bars	Deck Medium 7 Cross Bars	Deck Large 9 Cross Bars
BL Austin	Metro		Hatch	FP	up to	1990		CVG01	CVB126HD	CVL03	2	2					
BL Austin	Mini		Estate	FP	up to	1983		CVG01	CVB106HD	CVL03	2	2					
Citroën	Visa		Hatch	FP	1978	1991		CVG01	CVB126HD	CVL03	2	2					
Citroën	C15 Champ		Hi Cube	NR	1985	2005							229500			270500	
Citroën	Jumper Low Roof			NR	1996	on	(2nd & 3rd Generation)						293523				
Citroën	Jumpy			NR	1996	2006								229590		270590	
Citroën	Jumpy			NR	2007	on	(2nd Generation)								229580		270580
Citroën	Berlingo		Hi Cube	FP	1996	2003		CVS04	CVB126HD	CVL01	2	3					
Citroën	Berlingo		Hi Cube	FP	2003	2007		CVS04	CVB126HD	CVL01	2	3					
Citroën	Berlingo		Hi Cube	NR	2008	on	(MKII)										
Citroën	Berlingo II (Hayon) (v.u.)			FP	05/2008	on	(MKII)							229600		270600	
Citroën	Xsara		Estate	NR	1997	2004		785999+786038	774061	Incl				229600		270600	
Citroën	Dispatch		Panel	FP	1996	2006		CVS06	CVB126HD	CVL01	2	2					
Citroën	Dispatch		Panel	FP	2007	on	(2nd Generation)	CVS16	CVB159HD	CVL01	2	5					
Citroën	Nemo		Hi Cube	FP	2008	on	(3rd Generation)	CVS16	CVB159HD	CVL01	2	3		229590	229620	270590	
Citroën	Relay		Panel	FP	1995	2002		CVS03	CVB190HD		2	4	293523				
Citroën	Relay Semi High Roof	SHR	Panel	FP	1995	2002		CVS03	CVB190HD		2	4					
Citroën	Relay High Roof	HR	Panel	FP	1995	2002		CVS03	CVB190HD		2	4					
Citroën	Relay		Panel	FP	2002	2006		CVS03	CVB190HD		2	4	293523				
Citroën	Relay Semi High Roof	SHR	Panel	FP	2002	2006		CVS03	CVB190HD		2	4					
Citroën	Relay Low Roof SWB	LR SWB	Panel	FP	2006	on	(3rd Generation)	CVS15	CVB159HD		2	5	293523				
Citroën	Relay Low Roof MWB	LR MWB	Panel	FP	2006	on	(3rd Generation)	CVS15	CVB159HD		2	5	293523				
Citroën	Relay High Roof MWB	HR MWB	Panel	FP	2006	on	(3rd Generation)	CVS15	CVB159HD		2	5					
Citroën	Relay High Roof LWB	HR LWB	Panel	FP	2006	on	(3rd Generation)	CVS15	CVB159HD		2	5					
Citroën	Relay High Roof LWB Heavy	HR LWB	Panel	FP	2006	on	(3rd Generation)	CVS15	CVB159HD		2	5					
Dacia	Logan		MPV / Van	NR	2007	2012								229550		270550	
Dacia	Dokker		Van	FP	2012	on	(1st Generation)							229550			
Fiat	Fiorino		Hi Cube	FP	1987	1991								229500		270500	
Fiat	Fiorino		Hi Cube	FP	1991	1994								229500		270500	
Fiat	Fiorino		Hi Cube	FP	1994	1997								229500		270500	
Fiat	Fiorino		Hi Cube	FP	1997	2001								229500		270500	
Fiat	Fiorino		Hi Cube	FP	2002	2006								229500		270500	
Fiat	Fiorino		Hi Cube	FP	2008	on	(3rd Generation)	CVS16	CVB159HD	CVL01	2	3		229590	229620	270590	
Fiat	Scudo		Panel	FP	1996	2003		CVS06	CVB126HD	CVL01	2	5		229590		270590	
Fiat	Scudo		Panel	FP	2003	2006		CVS06	CVB126HD	CVL01	2	5		229590		270590	
Fiat	Scudo		Panel	FP	2007	2016		CVS16	CVB159HD	CVL01	2	5			229580		270580
Fiat	Doblo		Panel	FP	2001	2009		CVS09	CVB126HD	CVL01	2	2		229600	229610	270600	
Fiat	Doblo II		Panel	FP	2010	on	(MKII)							229630			
Fiat	Ducato		Panel	FP	1994	2002		CVS03	CVB190HD		2	4	293523				
Fiat	Ducato Semi High Roof	SHR	Panel	FP	1994	2002		CVS03	CVB190HD		2	4					
Fiat	Ducato High Roof	HR	Panel	FP	1994	2002		CVS03	CVB190HD		2	4					

FP = Fixpoint RR = Open Roof Rails NR = Standard Roof

SWB = Short Wheel Base MWB = Medium Wheel Base LWB = Long Wheel Base LR = Low Roof MR = Medium Roof SHR = Semi High Roof HR = High Roof OC = Over Cab DC = Double Cab SC = Super Cab

MONT BLANC COMMERCIAL ROOF BAR GUIDE - 18/03/2016

VEHICLE DETAILS								MB ProRack						MB ProRack				
MANUFACTURER	MODEL	TYPE	BODY STYLE	BODY STYLE CODE	YEAR START	YEAR END	MODEL REFERENCE	PRORACK FOOT PACKS (Sold In Pairs, 2 Feet)	PRORACK ROOF BARS (Single Bar)	PRORACK LOCKS	MIN NO. BARS	MAX NO. OF BARS	Rack Large 3 Bars	Rack Medium 2 Bars	Rack Medium 3 Bars	Deck Medium 7 Cross Bars	Deck Large 9 Cross Bars	
Fiat	Ducato		Panel	FP	2002	2006		CVS03	CVB190HD		2	4	293523					
Fiat	Ducato Semi High Roof	SHR	Panel	FP	2002	2006		CVS03	CVB190HD		2	4						
Fiat	Ducato Low Roof SWB (LR SWB	Panel	FP	2006	on	(3rd Generation)	CVS15	CVB159HD		2	5						
Fiat	Ducato Low Roof MWB	LR MWB	Panel	FP	2006	on	(3rd Generation)	CVS15	CVB159HD		2	5						
Fiat	Ducato Med Roof MWB	MR MWB	Panel	FP	2006	on	(3rd Generation)	CVS15	CVB159HD		2	5						
Fiat	Ducato Med Roof LWB	MR LWB	Panel	FP	2006	on	(3rd Generation)	CVS15	CVB159HD		2	5						
Fiat	Ducato High Roof LWB	HR LWB	Panel	FP	2006	on	(3rd Generation)	CVS15	CVB159HD		2	5						
Fiat	Ducato Med Roof LWB XL	MR LWB	Panel	FP	2006	on	(3rd Generation)	CVS15	CVB159HD		2	5						
Fiat	Ducato High Roof LWB XL	HR LWB	Panel	FP	2006	on	(3rd Generation)	CVS15	CVB159HD		2	5						
Ford	Courier Kombi		Hi Cube	FP	1992	1996								229500		270500		
Ford	Fiesta		Hatch	FP	up to	1983		CVG01	CVB126HD	CVL03	2	2						
Ford	Fiesta		Hatch	FP	1983	1989		CVG01	CVB126HD	CVL03	2	2						
Ford	Fiesta		Hatch	NR	1989	1996		CVG01	CVB126HD		2	2						
Ford	Fiesta		Hatch	NR	1996	2002		CVG01	CVB126HD		2	2						
Ford	Escort		Hatch	FP	up to	1980		CVG01	CVB126HD	CVL03	2	2						
Ford	Escort		Hi Cube	FP	1980	1990		CVG01	CVB126HD	CVL03	2	2						
Ford	Escort 3 Bar System		Hi Cube	NR	1990	2002		CVG02x1+CVG01x2	CVB126HD x 3		3	3						
Ford	Escort 2 Bar System		Hi Cube	NR	1990	2002		CVG01	CVB126HD	CVL03	2	2						
Ford	Escort Over Cab Bar only	OC	Hi Cube	NR	1990	2002		CVG02	CVB126HD		1	1						
Ford	Tourneo Low Roof		Panel	FP	2003	2013							229550		270550			
Ford	Ranger		4x4 Pickup	NR	2003	2011		785998+786128	774251	Incl								
Ford	Ranger DCab	DC	4x4 Pickup	NR	1998	2011		785998+786128	774251	Incl								
Ford	Ranger Super Cab	SC	4x4 Pickup	NR	1998	2011		785998+786128	774251	Incl								
Ford	Transit Connect SWB	SWB	Panel	FP	2002	2013		CVS09	CVB126HD	CVL01	2	2	229550		270550			
Ford	Transit Connect LWB	LWB	Panel	FP	2002	2013		CVS09	CVB126HD	CVL01	2	2	229550		270550			
Ford	Transit Connect LWB High Roof	HR LWB	Panel	FP	2002	2013		CVS09	CVB126HD	CVL01	2	2						
Ford	Transit SWB	SWB	Panel	FP	2000	2006		CVG01	CVB190HD	CVL03	2	4						
Ford	Transit SWB	SWB	Panel	FP	2006	2013		CVG01	CVB190HD	CVL03	2	5						
Iveco	Daily 29L			NR	2000	on							293524					
Iveco	Daily 35C			NR	2000	on							293524					
Iveco	Daily 35S			NR	2000	on							293524					
Iveco	Daily S2000			NR	2000	on							293524					
IvecoFord	Daily		Panel	NR	1999	2003		CVS03	CVB190HD		2	3						
IvecoFord	Daily		Panel	NR	2004	2014		CVS03	CVB190HD		2	3						
IvecoFord	Daily High Roof	HR	Panel	NR	1999	2003		CVS03	CVB159HD		2	3						
IvecoFord	Daily High Roof	HR	Panel	NR	2004	2014		CVS03	CVB190HD		2	3						
Lada	Samara		Hatch	FP	1984	2013		CVG01	CVB126HD	CVL03	2	2						
Land Rover	Freelander		4x4	RR	1999	2006		787020	774061	Incl	2	2						
Mazda	BSeries		4x4 Pickup	NR	1999	2006		785998+786128	774251	Incl	2	2						
Mazda	BT50		4x4 Pickup	NR	2006	2011		785998+786128	774251	Incl	2	2						
MercedesBenz	Citan	LR	Panel	FP	2012	on							229550		270550			
MercedesBenz	Class v			FP	1997	2003							229540			270540		
MercedesBenz	Vito (W638)		Panel	FP	1996	2003		CVS07	CVB159HD	CVL01	2	4	229540				270540	
MercedesBenz	Vito (W639)		Panel	FP	2003	2014		CVS16	CVB159HD	CVL01	2	2						
MercedesBenz	Vito SWB (W639)	SWB	Panel	FP	2003	2014		CVS16	CVB159HD	CVL01	2	4						

FP = Fixpoint RR = Open Roof Rails NR = Standard Roof

SWB = Short Wheel Base MWB = Medium Wheel Base LWB = Long Wheel Base LR = Low Roof MR = Medium Roof SHR = Semi High Roof HR = High Roof OC = Over Cab DC = Double Cab SC = Super Cab

MONT BLANC COMMERCIAL ROOF BAR GUIDE - 18/03/2016

VEHICLE DETAILS								MB ProRack					MB ProRack				
MANUFACTURER	MODEL	TYPE	BODY STYLE	BODY STYLE CODE	YEAR START	YEAR END	MODEL REFERENCE	PRORACK FOOT PACKS (Sold In Pairs, 2 Feet)	PRORACK ROOF BARS (Single Bar)	PRORACK LOCKS	MIN NO. BARS	MAX NO. OF BARS	Rack Large 3 Bars	Rack Medium 2 Bars	Rack Medium 3 Bars	Deck Medium 7 Cross Bars	Deck Large 9 Cross Bars
MercedesBenz	Vito MWB (W639)	MWB	Panel	FP	2003	2014		CVS16	CVB159HD	CVL01	2	4					
MercedesBenz	Vito LWB (W639)	LWB	Panel	FP	2003	2014		CVS16	CVB159HD	CVL01	2	4					
Mitsubishi	L200 (doublecab)	DC	4x4 Pickup	NR	1998	2006		785998+786003	774251	Incl	2	2					
Mitsubishi	Shogun		4x4	RR	2001	2005		796701		CVL01	2	2					
Mitsubishi	Shogun Pinin		4x4	RR	2000	2005		796701		CVL01	2	2					
Nissan	Patrol 4WD		4x4	FP	1982	2009		CVG01	CVB159HD	CVL03	2	2					
Nissan	Cubic			NR	1994	on	(Z10, Z11, Z12)						229500			270500	
Nissan	Kubistar		Panel	FP	2003	2009		CVS09	CVB106HD	CVL01	2	2		229550		270550	
Nissan	Primastar Low Roof SWB	LR SWB	Panel	FP	2001	9/2014	(X83)	CVS13	CVB159HD	CVL01	2	4			229580		270580
Nissan	Primastar Low Roof LWB	LR LWB	Panel	FP	2001	9/2014	(X83)	CVS13	CVB159HD	CVL01	2	4			229580		270580
Nissan	Interstar Low Roof SWB	LR SWB	Panel	FP	1999	2009		CVS17	CVB159HD		2	3			229580		270580
Nissan	Interstar High Roof SWB	HR SWB	Panel	FP	1999	2010		CVS17	CVB159HD		2	3					
Nissan	Interstar High Roof MWB	HR MWB	Panel	FP	1999	2010		CVS17	CVB159HD		2	4					
Nissan	Interstar Maxi Roof MWB	MR MWB	Panel	FP	1999	2010		CVS17	CVB159HD		2	4					
Nissan	Interstar High Roof LWB	HR LWB	Panel	FP	1999	2010		CVS17	CVB159HD		2	4					
Nissan	Interstar Maxi Roof LWB	MR LWB	Panel	FP	1999	2010		CVS17	CVB159HD		2	4					
Nissan	NV200		Panel	NR	2010	on	(MKI)						229550			270550	
Nissan	NV400		Panel	FP	2010	on	(3rd Generation)							229580			
Nissan	Terrano II		4x4	RR	1998	2006		796701		CVL01	2	2					
Opel	Combo			FP	1993	2001	(B)						229500			270500	
Opel	Combo		Panel	FP	2012	on	(D)						229630				
Opel	Movano		Panel	FP	1999	2009									229580		270580
Opel	Movano		Panel	FP	2010	on	(3rd Generation)								229580		
Opel	Vivaro Low Roof SWB	LR SWB	Panel	FP	2001	9/2014	(X83)								229580		270580
Opel	Vivaro Low Roof LWB	LR LWB	Panel	FP	2001	9/2014	(X83)								229580		270580
Opel	Vivaro	SWB	Panel	FP	10/2014	on	(X82)								229640		
Peugeot	205 Fourgonnette			NR	1996	1997							229500			270500	
Peugeot	305		Estate	FP	1983	1990		CVG01	CVB126HD	CVL03	2	2					
Peugeot	504		Estate	FP	1986	1994		CVG01	CVB159HD	CVL03	2	2					
Peugeot	BIPPER			FP	2008	on	(3rd Generation)	CVS16	CVB159HD	CVL01	2	3		229590		270590	
Peugeot	Boxer		Panel	FP	1994	2006		CVS03	CVB190HD		2	4	293523				
Peugeot	Boxer Semi High Roof	SHR	Panel	FP	1994	2006		CVS03	CVB190HD		2	4					
Peugeot	Boxer High Roof	HR	Panel	FP	1994	2006		CVS03	CVB190HD		2	4					
Peugeot	Boxer Low Roof SWB	LR SWB	Panel	FP	2007	on	(3rd Generation)	CVS15	CVB159HD		2	3	293523				
Peugeot	Boxer Low Roof MWB	LR MWB	Panel	FP	2007	on	(3rd Generation)	CVS15	CVB159HD		2	4	293523				
Peugeot	Boxer High Roof MWB	HR MWB	Panel	FP	2007	on	(3rd Generation)	CVS15	CVB159HD		2	4					
Peugeot	Boxer High Roof LWB	HR LWB	Panel	FP	2007	on	(3rd Generation)	CVS15	CVB159HD		2	5					
Peugeot	Expert		Panel	FP	1996	2006		CVS06	CVB126HD	CVL01	2	5		229590		270590	
Peugeot	Expert		Panel	FP	2007	on	(2nd Generation)	CVS16	CVB159HD	CVL01	2	5			229580		270580
Peugeot	Partner		Hi Cube	FP	1996	2003		CVS04	CVB126HD	CVL01	2	3					
Peugeot	Partner		Hi Cube	FP	2003	2007		CVS04	CVB126HD	CVL01	2	3					
Peugeot	Partner Teepee			NR	2008	on	(MKII)						229600			270600	
Peugeot	Partner		Hi Cube	NR	2007	on	(MKII)						229600			270600	
Renault	4		Hatch	FP	up to	1986		CVG01	CVB126HD	CVL03	2	2					
Renault	5		Hatch	FP	up to	1989		CVG01	CVB126HD	CVL03	2	2					

FP = Fixpoint RR = Open Roof Rails NR = Standard Roof

SWB = Short Wheel Base MWB = Medium Wheel Base LWB = Long Wheel Base LR = Low Roof MR = Medium Roof SHR = Semi High Roof HR = High Roof OC = Over Cab DC = Double Cab SC = Super Cab

MONT BLANC COMMERCIAL ROOF BAR GUIDE - 18/03/2016

VEHICLE DETAILS								MB ProRack					MB ProRack				
MANUFACTURER	MODEL	TYPE	BODY STYLE	BODY STYLE CODE	YEAR START	YEAR END	MODEL REFERENCE	PRORACK FOOT PACKS (Sold In Pairs, 2 Feet)	PRORACK ROOF BARS (Single Bar)	PRORACK LOCKS	MIN NO. BARS	MAX NO. OF BARS	Rack Large 3 Bars	Rack Medium 2 Bars	Rack Medium 3 Bars	Deck Medium 7 Cross Bars	Deck Large 9 Cross Bars
Renault	Kangoo		Hi Cube	FP	1998	2008		CVS09	CVB126HD	CVL01	2	2		229550		270550	
Renault	Kangoo		Hi Cube	NR	2009	on	(MKII)							229550		270550	
Renault	Kangoo Express Maxi		Hi Cube	FP	2010	on	(MKII)							229550		270550	
Renault	Master Low Roof SWB	LR SWB	Panel	FP	1998	2010		CVS17	CVB159HD		2	3			229580		270580
Renault	Master Low Roof SWB	LR SWB	Panel	FP	2010	on	(3rd Generation)								229580		
Renault	Master High Roof SWB	HR SWB	Panel	FP	1998	2010		CVS17	CVB159HD		2	3					
Renault	Master High Roof MWB	HR MWB	Panel	FP	1998	2010		CVS17	CVB159HD		2	4					
Renault	Master Maxi Roof MWB	MR MWB	Panel	FP	1998	2010		CVS17	CVB159HD		2	4					
Renault	Master High Roof LWB	HR LWB	Panel	FP	1998	2010		CVS17	CVB159HD		2	4					
Renault	Master Maxi Roof LWB	MR LWB	Panel	FP	1998	2010		CVS17	CVB159HD		2	4					
Renault	Trafic Low Roof SWB	LR SWB	Panel	FP	2001	9/2014	(X83)	CVS13	CVB159HD	CVL01	2	4			229580		270580
Renault	Trafic Low Roof LWB	LR LWB	Panel	FP	2001	9/2014	(X83)	CVS13	CVB159HD	CVL01	2	4			229580		270580
Renault	Trafic Low Roof SWB	LR SWB	Panel	FP	10/2014	on	(X82)								229640		
Rover	Metro		Hatch	FP	up to	1990		CVG01	CVB126HD	CVL03	2	2					
Seat	Inca		Hi Cube	FP	up to	1996		CVS06	CVB106HD	CVL01	2	2					
Seat	Inca		Hi Cube	FP	1996	2004								229520		270520	
Subaru	Justy		Hatch	FP	1988	1994		CVG01	CVB106HD	CVL03	2	2					
Toyota	Hiace Power		Panel	FP	1996	2001		CVS05	CVB159HD		2	3					
Toyota	Hiace Power 280 SWB	SWB	Panel	FP	2002	on	(H200)	CVS05	CVB159HD		2	4					
Toyota	Hiace Power 300 LWB	LWB	Panel	FP	2002	on	(H200)	CVS05	CVB159HD		2	4					
Toyota	Proace				2013	on	(2nd Generation)								229580		270580
Vauxhall	Astra Max		Estate	NR	1985	1993		CVG01	CVB126HD		2	2					
Vauxhall	Astra		Hatch	FP	1982	1984		CVG01	CVB126HD	CVL03	2	2					
Vauxhall	Astra		Estate	NR	1993	2006		CVG01	CVB126HD		2	2					
Vauxhall	Chevette		Hatch	FP	1976	1982		CVG01	CVB106HD	CVL03	2	3					
Vauxhall	Combo		Hi Cube	FP	1994	2001		CVS01	CVB126HD		2	2					
Vauxhall	Combo		Hi Cube	FP	2002	2008		CVS01	CVB126HD		2	2					
Vauxhall	Combo		Hi Cube	FP	2008	2011		CVS01	CVB126HD		2	2					
Vauxhall	Combo		Panel	FP	2012	on	(MKIV)							229630			
Vauxhall	Corsavan		Hatch	NR	1994	2001		CVG01	CVB126HD		2	2					
Vauxhall	Corsavan		Hatch	NR	2002	2007		CVG01	CVB126HD		2	2					
Vauxhall	Movano Low Roof SWB	LR SWB	Panel	FP	1999	2009		CVS17	CVB159HD		2	3			229580		270580
Vauxhall	Movano Low Roof SWB	LR SWB	Panel	FP	2010	on	(3rd Generation)							229580			
Vauxhall	Movano High Roof SWB	HR SWB	Panel	FP	1999	2010		CVS17	CVB159HD		2	3					
Vauxhall	Movano High Roof MWB	HR MWB	Panel	FP	1999	2010		CVS17	CVB159HD		2	4					
Vauxhall	Movano Maxi Roof MWB	MR MWB	Panel	FP	1999	2010		CVS17	CVB159HD		2	4					
Vauxhall	Movano High Roof LWB	HR LWB	Panel	FP	1999	2010		CVS17	CVB159HD		2	4					
Vauxhall	Movano Maxi Roof LWB	MR LWB	Panel	FP	1999	2010		CVS17	CVB159HD		2	4					
Vauxhall	Nova		Hatch	FP	1990	1993		CVG01	CVB106HD	CVL03	2	2					
Vauxhall	Vivaro Low Roof SWB	LR SWB	Panel	FP	2001	9/2014	(X83)	CVS13	CVB159HD	CVL01	2	4			229580		270580
Vauxhall	Vivaro Low Roof LWB	LR LWB	Panel	FP	2001	9/2014	(X83)	CVS13	CVB159HD	CVL01	2	4					
Vauxhall	Vivaro Low Roof SWB	LR SWB	Panel	FP	10/2014	on	(X82)								229640		
Volkswagen	Caddy		Hi Cube	FP	1979	1996		CVS06	CVB106HD	CVL01	2	2					
Volkswagen	Caddy		Hi Cube	FP	1997	2004								229520		270520	
Volkswagen	Caddy		Panel	FP	2004	2010		CVS14	CVB126HD	CVL01	2	2			229550		270550

FP = Fixpoint RR = Open Roof Rails NR = Standard Roof

SWB = Short Wheel Base MWB = Medium Wheel Base LWB = Long Wheel Base LR = Low Roof MR = Medium Roof SHR = Semi High Roof HR = High Roof OC = Over Cab DC = Double Cab SC = Super Cab

MONT BLANC COMMERCIAL ROOF BAR GUIDE - 18/03/2016

VEHICLE DETAILS								MB ProRack					MB ProRack				
MANUFACTURER	MODEL	TYPE	BODY STYLE	BODY STYLE CODE	YEAR START	YEAR END	MODEL REFERENCE	PRORACK FOOT PACKS (Sold In Pairs, 2 Feet)	PRORACK ROOF BARS (Single Bar)	PRORACK LOCKS	MIN NO. BARS	MAX NO. OF BARS	Rack Large 3 Bars	Rack Medium 2 Bars	Rack Medium 3 Bars	Deck Medium 7 Cross Bars	Deck Large 9 Cross Bars
Volkswagen	Caravelle		MPV	FP	2003	2014	(T5)	CVS12	CVB159HD	CVL01	2	2					
Volkswagen	Polo Van		Hatch	FP	1986	1994		CVG01	CVB106HD	CVL03	2	2					
Volkswagen	Transporter		Panel	NR	1990	2003		CVS02	CVB159HD	CVL01	2	2					
Volkswagen	Transporter Low Roof SWB	LR SWB	Panel	FP	2003	2010		CVS12	CVB159HD	CVL01	2	4					
Volkswagen	Transporter Low Roof LWB	LR SWB	Panel	FP	2003	2010		CVS12	CVB159HD	CVL01	2	4					

FP = Fixpoint RR = Open Roof Rails NR = Standard Roof

SWB = Short Wheel Base MWB = Medium Wheel Base LWB = Long Wheel Base LR = Low Roof MR = Medium Roof SHR = Semi High Roof HR = High Roof OC = Over Cab DC = Double Cab SC = Super Cab

MONT BLANC COMMERCIAL ROOF BAR GUIDE - 18/03/2016

How to Use Guide

MB ProRange Rack

1 or 2 piece roof bar system. Foot packs with part numbers that start either CVG, CVH or CVS are sold in pairs, (2 feet). Roof Bars CVB are sold in singles. Therefore, for example a two bar option for a Peugeot Boxer SWB 2006 - on would be CVS15 x 2 and CVB159HD x 2. Locks in many cases are available and can be purchased separately. Information on the minimum and maximum amount of bars that can be fitted per vehicle is also identified.

MB ProRange Rack / Deck

1 piece complete roof Rack or Deck system. First 3 columns are Roof Racks available with either 2 or 3 bars. Final 2 columns are our Deck systems available with either 7 or 9 cross bars.

Find your vehicle

VEHICLE DETAILS							MB ProRack					MB ProRack				
MANUFACTURER	MODEL	TYPE	BODY STYLE	BODY STYLE CODE	YEAR START	YEAR END	PRORACK FOOT PACKS (Sold in Pairs, 2 Feet)	PRORACK ROOF BARS (Single Bars)	PRORACK LOCKS	MIN NO. BARS	MAX NO. OF BARS	Rack Large 3 Bars	Rack Medium 2 Bars	Rack Medium 3 Bars	Deck Medium 7 Cross Bars	Deck Large 9 Cross Bars
Peugeot	Boxer Low Roof SWB	LR SWB	Panel	FP	2006	on	CVS15	CVB159HD		2	3	293523				
Peugeot	Boxer Low Roof MWB	LR MWB	Panel	FP	2006	on	CVS15	CVB159HD		2	4					
Peugeot	Boxer High Roof MWB	HR MWB	Panel	FP	2006	on	CVS15	CVB159HD		2	4					
Peugeot	Boxer High Roof LWB	HR LWB	Panel	FP	2006	on	CVS15	CVB159HD		2	5					
Peugeot	Expert		Panel	FP	1996	2007	CVS06	CVB126HD	CVL01	2	5		229590		270590	
Peugeot	Expert		Panel	FP	2007	on	CVS16	CVB159HD	CVL01	2	5			229580		270580
Peugeot	Partner		Hi Cube	FP	1996	2003	CVS04	CVB126HD	CVL01	2	3					
Peugeot	Partner		Hi Cube	FP	2003	2007	CVS04	CVB126HD	CVL01	2	3					
Peugeot	Partner Teepee			NR	2008	on							229600		270600	
Peugeot	Partner		Hi Cube	NR	2007								229600		270600	

FP = Fixpoint RR = Open Roof Rails NR = Standard Roof

SWB = Short Wheel Base MWB = Medium Wheel Base LWB = Long Wheel Base LR = Low Roof MR = Medium Roof SHR = Semi High Roof HR = High Roof OC = Over Cab DC = Double Cab SC = Super Cab

MONT BLANC COMMERCIAL ROOF BAR GUIDE - 18/03/2016

ProRack - Racks

1 piece commercial roof Bar system for fixed point vehicles. Subject to application, available with either 2 or 3 bars. Strong, durable and easy to assemble. All steel components are coated to provide high level corrosion resistances. Comes with 3 year warranty.



ProRack - Decks

1 piece commercial roof deck system for fixed point vehicles. Subject to application available with either 7 or 9 cross bars. Strong, durable and easy to assemble. All steel components are coated to provide high level corrosion resistances. Comes with 3 year warranty.



ProRack - Bars CVGXX

2 piece commercial roof bar system for guttered vehicles. Foot packs are compatible with our high strength CVB 30mm x 40mm load bars only. Strong, durable and easy to assemble. All steel components are coated to provide high level corrosion resistances. Subject to application, additional bars can be purchased to fit up to a maximum of 5 bars per vehicle. Comes with 3 year warranty.



ProRack - Bars CVSXX

2 piece commercial roof bar system for gutterless or fixed point vehicles. Foot packs are compatible with our high strength CVB 30mm x 40mm load bars only. Strong, durable and easy to assemble. All steel components are coated to provide high level corrosion resistances. Subject to application, additional bars can be purchased to fit up to a maximum of 5 bars per vehicle. Comes with 3 year warranty.



Notes: Please ensure your application list is up to date by visiting the Mont Blanc website: www.montblancgroup.com. Not all products listed on the website may be available in the UK.

Mont Blanc has a policy of continued development and reserves the right to change specifications without notice.

FP = Fixpoint RR = Open Roof Rails NR = Standard Roof

SWB = Short Wheel Base MWB = Medium Wheel Base LWB = Long Wheel Base LR = Low Roof MR = Medium Roof SHR = Semi High Roof HR = High Roof OC = Over Cab DC = Double Cab SC = Super Cab